

RF SERIES

INTERFACE APPLICATIONS



BRIDGE BARS FOR COIL AND POWER LINES

BF34, BF31

Power bridge bars for sockets SFR10 and SFB20 bridges join four similar points in four aside adjacent sockets. They can join up either among themselves or to BF31 units, to bridge an unlimited number of sockets SFR10 and SFB20 in any combination. BF31 bridges are units to connect a single socket to the next one, so you bridge less or more than 4 sockets. Made of copper with a current capacity of 40 A.

BF24

Coil bridge bars for sockets SFR10 and SFB20 bridges points A 2, internally connected, of every aside adjacent socket SFR10 or SFB20. Each element connects point 6 of the first socket to point 5 of the next one, always leaving free the point 5 of the first socket and the point 6 of the last one, to connect the common polarity cable.

BF14

These bridge bars are suitable for sockets SFB10. It can be used as coil circuit or contact circuit. The bridges must be inserted in the slot of the socket. The max current through bridges is 10 A and they can be separated manually.

BF34-G



BF31-G



BF24-G



BF14-G



BF34-R



BF31-R



BF24-R



BF34-A



BF31-B



BF24-B

